10kW All-in-one the Hybrid Inverter User Manual

Important Notice

In order to protect the legitimate rights and interests of users, please read our operating procedures and safety instructions carefully before using this equipment. Please operate the equipment according to the operating procedures and safety instructions.

Once using this device, you are deemed to have read, understood, endorsed and accepted all terms and contents of the device's operating procedures and safety instructions. The user is committed to being responsible for his or her own actions and all consequences arising therefrom.

The User undertakes to use the device solely for legitimate purposes and agrees to these Terms and any relevant national policies or guidelines.

In the process of using this equipment, please strictly observe and implement the requirements including but not limited to the operating procedures and safety instructions. All personal injury, accident, property damage, legal disputes and other adverse events that cause conflicts of interest caused by violations of the use instructions or force majeure indicated by the safety instructions are the responsibility and loss of the user. Our company will We do not assume any responsibility.

Copyright, all rights reserved. The content is subject to change without notice.

\wedge	Caution!
<u>/!\</u>	Failure to observe a warning indicated in this manual may result in injury.
\land	Danger of high voltage and electric shock!
	Refer to the operating instructions
	Signals danger due to electrical shock and indicates the time(5 minutes)to
14	allow after the inverter has been turned off and disconnected to ensure
5mins	safety in any installation operation.
	Danger of hot surface!
	Protective earth

Installation Risk Notification

	Wear protective gloves when handling equipment by hand to prevent cuts from sharp objects.
Attention	Make sure the cable label is correct before connecting the cable.
Dangerous	Construction operation of high-voltage lines may cause fire or electric shock. The area through which the AC cable is connected and routed must comply with local regulations and specifications.

Please carry out construction in accordance with relevant construction safety regulations and standards to avoid safety accidents. The person who is in charge of this product must undergo strict training, master the correct installation method of the system and various safety precautions before proceeding with the equipment.

The installation location should avoid the location of low-lying water accumulation and should be kept at a safe distance from the surrounding fire-explosive facilities and underground pipelines. The installation location should be away from open flames, high temperature, dust and corrosive environment. The protection grade of the selected product enclosure should be compared with the installation environment adapt.

The installation position strength must meet the requirements, all fixing bolts should be tightened, otherwise there is a risk of falling and dumping. Install the selected cables, terminals and other components to meet the current requirements. Before and after installation, ensure that all wiring related to the charging equipment is tight, well insulated, wired correctly, no wear and crush damage, otherwise there is a risk of fire and electric shock.

Before powering on the device, be sure to confirm that the device is well grounded to avoid electric shock. If any part is damaged during installation, it should be repaired and replaced in time to avoid using with damaged.

Operation and maintenance risk notification

Dangerous	There is dangerous voltage in the equipment when the system is running, and non-professionals should not operate and maintain it.
Dangerous	Before the maintenance of system clean, electrical connection, ground connection, be sure to cut off power . Otherwise, there is a risk of electric shock and fire.

Equipment operation and maintenance must comply with electrical safety operating procedures, otherwise there is a risk of fire and electric shock.

The personnel responsible for the operation and maintenance of this product must have the qualifications of high voltage and alternating current, etc., and must undergo strict training, master the correct operation method of the system and various safety precautions, and then carry out various operations of the equipment, otherwise there may be risk of electric shock.

The energy storage equipment shall not be maintained when the power is not disconnected, otherwise there will be risk of electric shock.

It is strictly forbidden to wear conductive objects such as watches, bracelets, rings, etc. on the wrist during operation.

Do not dismantle or modify the charging facilities and wiring without authorization, otherwise it may cause fire or electric shock.

There shall be no flammable and combustible materials around the energy storage equipment, and the operation and maintenance personnel shall clean up in time, otherwise there is a fire risk.

Use risk notification

Do not use the system in the event of equipment failure. Do not operate without authorization when the equipment is abnormal.

Please strictly follow the operating procedures and instructions on the energy storage equipment, and must comply with the industry's safety regulations, otherwise there will be electric shock and fire risks.

Accidents such as fires, flooding of energy storage facilities, etc. it is strictly forbidden to be close to energy storage equipment. Please inform personnel familiar with equipment and emergency treatment methods for emergency treatment.

Modification record

 The Document version
 A00 (2019.03.04)

 The First release

 The Document version
 A01 (2019.05.07)

 1.2
 Modify Working Mode

 2.3.2
 Add electrical connection diagram

 3.1
 Update pictures of APP

 3.6.2
 Note about Battery Lower Limit SOC

 4.2
 Add Software upgrade

 5.3
 Update Trouble Shooting

 The Document version
 A02 (2019.08.20)

 2.2.2
 Modify Working Mode

2.3.2.4 Modify Software update

Catalogue

1 Summary	. 1
1.1 The description of type	. 1
1.2 Compose and Operating principle	. 1
2 Installation	6
2.1 Safety regulations	6
2.2 Installation preparation	6
2.3 Installation 1	10
2.4 Installation check	22
3 Sun mate APP	23
3.1 Software acquisition	23
3.2 Connect to internal Wi-Fi	23
3.3 Home page	25
3.4 Parameter	25
3.5 Warning2	29
3.6 Setting	31
4 System commissioning	35
4.1 Commissioning	36
4.2 Software upgrade	39
5 Product maintenance 4	42
5.1 Routine maintenance 4	43
5.2 LED Status 4	44
5.3 Trouble shooting4	45
6 Technical parameters	49



1 SUMMARY

The 10kW Hybrid Inverter all-in-one inverter (hereinafter referred to as the Hybrid Inverter) can realize Hybrid Inverter for photovoltaic charging, DC terminal battery charging and discharging, and AC terminal grid-connected applications.

This chapter describes the model, composition and configuration and working principle of the Hybrid Inverter.

1.1 The description of type

Take 10kW power as an example for model description. Hybrid Inverter model: SMT-10K-TL-TH The model description is shown below:





1.2 Compose and Operating Principle

The Hybrid Inverter is composed of a power unit (battery charging and discharging circuit, photovoltaic lifting and lowering voltage circuit, inverter circuit,, auxiliary power source, filter circuit), system control unit, and system monitoring unit (including a system communication unit), etc.

This product generally applies to solar storage system, the system is mainly composed of PV panel, battery, hybrid inverter, local load, grid etc. By dint of EMS, it can realize the functions for PV grid-connected, supplying local load from PV, charging battery from PV, charging local load from PV and battery, charging batter from grid. These five core functions are designed to ensure high effective PV generation, reliable supply for local load, long service life of battery, etc.



The schematic diagram of the main circuit of the Hybrid Inverter is as follows:



Figure1-2 The Hybrid Inverter principle topology

Work Modes:

Four working modes: General mode, Battery mode, Micro-grid mode, Peak Cut mode.

The client must set up in APP before running the inverter: working parameters (grid codes, battery type), parameter of working mode (working mode, grid-connected power, battery SOC lower limit), pricing setting, period setting.

As shown in figure below:





Mode 1: General mode (Default)

Self-Consumption

1. If PV is sufficient, PV supply power to the load priority, then charge battery, feeding into grid with surplus power. (Figure1-5)

2.When PV is insufficient, batteries and grid supply power to the load together. (Figure1-6) 3.Anti-backflow default disenablement.

Typical application scenarios:



Mode 2: Battery mode

Battery backup

1.PV and grid supply power to load and charge batteries together. (Figure 1-7)

2.When the Grid is normal, the battery SOC is always in full state.

3.Batteries discharge only when the grid is abnormal.

4.Anti-backflow default enablement.

Typical application scenarios:





Mode 3: Micro-grid mode

Suitable for non-grid scenarios

1.PV and battery constitute a off-grid system.

2.If PV is sufficient, PV supply power to the load priority, then charge battery. (Figure1-10)

3.When PV is insufficient, Batteries supply power to the load. (Figure1-11)

Typical application scenarios:



Mode 4: Custom mode

According to the difference of electricity price, a day can be divided into four periods: tip, peak, flat and valley.

1. In the valley level, the grid and PV charge the batteries.

2. In the Flat level, when the PV is sufficient, the battery can be charged.

3. In the tip and peak level, the battery discharges supply the load.

Typical application scenarios:





In Valley Time Period:





In Flat Time Period: :







In Tip and Peak Time Period:



Figure1-16 PV is insufficient



Figure1-15 PV is sufficient

Figure1-17 PV is sufficient

.oad



2 INSTALLATION

This chapter describes the installation and wiring of the Hybrid Inverter. Please strictly follow the instructions in this chapter to install and wire connection.

2.1 Safety regulations

The Hybrid Inverter has high voltage and large current inside. To ensure personal safety, the following regulations should be observed at all times.

The Hybrid Inverter can only be installed by personnel who have received training in the Hybrid Inverter and have a good knowledge of the Hybrid Inverter. During the installation process, always observe the safety precautions and local safety regulations before the catalogue of this manual;

Do not operate or maintain the inside of the system during thunderstorms or wet weather to prevent electric shock;

If operating inside the Hybrid Inverter, make sure the system is not powered

If hybrid inverter is equipped with anti-theft lock, please be sure of key in safekeeping.

2.2 Installation preparation

2.2.1 Unpacking inspection

Only when the goods arrive at the installation site can the unpacking box be allowed to be inspected. The inspection is completed by the customer's representative and the supplier's representative. Unpack the package, review the checklist.





Figure2-1 Packing list

2.2.2 The Hybrid Inverter Overview:



Figure 2-2 The Hybrid Inverter Overview



2.2.3 Cable and Air switch preparation

Serial	Cable Name	Recommended	cross-sectional	Color of cable	Cable
		model	area(mm²)		OD(mm)
1	PV side DC positive and negative input	PV1-F	4~6	Red, Black	ø4.5∼ø7.8
2	Battery side DC positive and negative input	PV1-F	6	Red, Black	ø4.5~ø7.8
3	AC output	UL1015 10AWG	4~6	Yellow, Green, Red, Blue, Yellow-Green	ø11~ø20

Note: Be sure of all cables' withstand voltage, temperature-resistance equaling to or

better than the recommended model, and complying with relevant regulation of electrical industry.

Selection of switch

Table 2-2

Recommended DC switch			
	PV(option) Battery(option)		
Rated voltage	≥1000V DC	≥800V DC	
Rated current	20A	32A	

Table 2-3

Recommended AC switch			
	AC Load	AC Grid	
Rated voltage	≥250V AC	≥250V AC	
Rated current	25A	25A	

2.2.4 Installation Kit

- 1. Electric drill (drilling bit: Ø 8mm)
- 2. Screwdriver (Philips screwdriver: M3, M6; Flat head screwdriver: M3)
- 3. Wire stripper(4,6mm²)
- 4. Wire crimper 1 (Model: H4TC0001; Manufacturer: Amphenol)
- 5.Wire crimper 2(OT terminal, 4~6 mm²)
- 6.Open-end wrench(Model: H4TW0001; manufacturer: Amphenol)
- 7.Multimeter



2.2.5 Installation requirements

1.Wall bracket Installation

1)It is necessary to ensure that the installation position is flat and the thickness of the whole wall exceeds 100mm;

2)Ensure the installation wall is vertical to the ground. If it is sloping , tilt angle is only allowed to be less than 15°

3)Ensure installation wall is solid enough to meet the requirements of load bearing for hybrid inverter.

4)The mounting position is supposed to avoid direct sunlight.



Figure 2-3 Perpendicularity requirement

2.Installation space requirements

Product installation position, leave 300 mm of space for maintenance and heat dissipation left, right and front



Figure 2-4 Mounting distance

Germatec

2.3 Installation

2.3.1 Mounting

STEP 1 : Mark mounting hole on the wall Drill hole with 8mm diameter of bit. Ensure a depth of 80mm.





STEP 2: Hammer expansion tube into the wall Mount bracket on the wall , keep aligned with the holes.





STEP 3: Mount the Sermatec hybrid inverter on the bracket.



Figure 2-7



STEP 4: Secure the inverters with M6 screw on the right side.



Figure 2-8

STEP 5: Install anti-theft lock if necessary(Option, equipped by user).



Figure 2-9



Hybrid Inverter System connection Diagram







For AU/EN





For Other Countries



Figure 2-12





1) Make sure all switches are at closed position before electrical connection.

2) Only qualified installation person can implement installation of AC and DC input cable.

2.3.2.1 Connect PV cable



It is strictly prohibited to connect positive pole(PV1+, PV2+, BAT+) and negative (PV1-, PV2-, BAT+) reversely or incorrectly. Otherwise it would affect normal operation, or even cause damage and other serious consequence.

The length of external cable to PV side and battery side is suggested to be less than 30m.

PV array should not be connected to the grounding conductor.

The minimum insulation resistance to ground of PV panels must exceed 33.3k, there is a risk of shock hazard if the requirement of minimum resistance is not met.

STEP 1: Check and verify PV rotary switch is at OFF position.



Figure 2-13



STEP 2: Follow the requirement to cramp and connect H4 connector to cable which you can find from installation kits.

Crimp the H4 connector to the cable as required.

PV cable size : 4~6 mm²





STEP 3: Use multimeter to measure PV side voltage and verify correct polarity , ensure open-circuit voltage is less than 1000V.



Figure 2-15 PV Polarity check

2.3.2.2. Connect BAT cable



Make sure that the installation location meets the following conditions:

The area is completely water proof.

The floor is flat and level.

Batteries should not be connected to the grounding conductor.

The ambient temperature is within the range from 0 $^\circ$ C to 50 $^\circ$ C.

The temperature and humidity is maintained at a constant level.

There is minimal dust and dirt in the area.

Batteries need to comply with local regulations.

Suggestion: If the battery is to be installed indoor, for details please refer to battery Manufacture's user manual.



Suggestion: Batteries must be installed with a distance to each other, details please refer to battery manufacture's user manual.

As for the number of cells used, it will be decided by customer's choice, the choice must comply with the followed requirement : the voltage is 200-800V.

Step 1: Crimp the H4 connector to the cable as required Battery cable size : 6 mm²



Figure 2-16

STEP 2: Use multimeter to measure Battery side voltage and verify correct polarity , ensure opencircuit voltage is less than 800V.

STEP 3: Connect positive and negative terminals to the corresponding interfaces.



Figure 2-17 DC terminals connection

2.3.2.3. AC output cable connection



Attention

PE cable should be connected properly and reliably , otherwise it would affect normal operation, even cause product damage and serious consequences.



Both PE ground terminal in the connector and ground point on enclosure can be earthed simultaneously.

Don't reversely connect PV input cable and battery input cable to interfaces ! Otherwise it will affect normal operation.

Don't reversely connect AC load connector and AC Grid connector, AC load cable and AC Grid cable! Otherwise it will affect normal operation.

STEP 1: Cable OD 16-20mm, pry inner ring out of connector.





STEP 2: The connector and cable are required to be reliably connected as shown below. Order of connection is 1-A (Yellow), 2-B (Green), 3-C (Red), 4-N (Blue), (P)-PE Cable sectional area 6 mm², stripping length 10±0.5mm



Figure 2-19



STEP 3: Measure grid voltage by multimeter, ensure grid voltage is less than high limit of voltage required by all national grid standard.



Note: Do not connect reverse the load side connector and the grid side connector.



Dangerous

Note: When AC LOAD or AC GRID is not in use, please tighten the connector cover, otherwise there will be electric shock danger, and the IP rating of the inverter will be reduced. STEP 4: Connect connector to AC Load interface and grid interface, rotate and lock them.



Figure 2-20

STEP 5: Clamp screw assembly





- 17 -



STEP 6: PE Installation

PE cable size : 4~6mm²



Figure 2-22

2.3.2.4. Communication cable connection

STEP 1: Remove the waterproof cover plate that comes with the Hybrid Inverter

STEP 2: Plug the wire connector of the waterproof cover plate in the accessory into the corresponding interface of the Hybrid Inverter.

STEP 3: Fix firmly by screw.

STEP 4: Screw up water-proof cylinder, connect the cable from "RS485" interface to the interface of Power Meter, connect the cable from "To battery" interface to BMS interface in battery (default length of cable is 3m)



Figure 2-23 Communication cable connection diagram



BMS and Power Meter Connection:



Figure 2-24

The RJ45 socket pin assignments for BMS and RS485 as follows:



	RS48	5
PIN	Signal Name	Cable Col
1	NC	Orange-wh
2	NC	Orange
3	485B_B	Green-whit
4	сом	Blue
5	сом	Blue-white
6	485B_A	Green
7	485B_B	Brown-whit
8	485B A	Brown

BMS			
PIN Signal Name Cable		Cable Color	
1	485A_B	Orange-white	
2	485A_A	Orange	
3	СОМ	Green-white	
4	CAN_H	Blue	
5	CAN_L	Blue-white	
6	СОМ	Green	
7	485A_A	Brown-white	
8	485A B	Brown	

Figure 2-25

2.3.2.5. DRED cable connection(Option)

STEP 1: Remove the water-proof cover plate that comes with the Hybrid Inverter.

STEP 2: Plug the wire connector of the water-proof cover plate in the accessory into the corresponding interface of the Hybrid Inverter.

STEP 3: Fix firmly by screw.

STEP 4: Screw up water-proof cylinder.



Figure 2-26



DRED cable connection diagram:



Figure 2-27

The RJ45 socket pin assignments for demand response modes as follows:

DRED			
PIN	Signal Name	Cable Color	
1	DRM 1/5	Orange-white	
2	DRM 2/6	Orange	
3	DRM 3/7	Green-white	
4	DRM 4/8	Blue	
5	RefGen	Blue-white	
6	Com/DRM0	Green	
7	N/A	Brown-white	
8	N/A	Brown	



Figure 2-28

The inverter shall detect and initiate a response to all supported demand response commands, demand response modes are described as follows: Table 2-4

Mode	Requirement
DRM 0	Operate the disconnection device
DRM 1	Do not consume power
DRM 2	Do not consume at more than 50% of rated power
DRM 3	Do not consume at more than 75% of rated power AND Source reactive power if capable
DRM 4	Increase power consumption(subject to constraints from other active DRMs)
DRM 5	Do not generate power
DRM 6	Do not generate at more than 50% of rated power
DRM 7	Do not generate at more than 75% of rated power AND Sink reactive power if capable.
DRM 8	Increase power generation(subject to constraints from other active DRMs)



2.3.2.6.GPRS Module(Optional) and Wi- Fi Antenna Connection

If the user selects the GPRS module, remove the dust cover plate of the GPRS module interface and install the GPRS module.



Figure 2-29

The GPRS socket pin assignments as follows:

PIN	Signal Name	
1	VCC	
2	GND	
3	485A	
4	485B	

Figure 2-30

Install the antenna to the antenna interface



Figure 2-31 WIFI antenna diagram



2.4 Installation check

Г

After the Hybrid Inverter is installed, be sure to check the installation according to the following table!

Check item	Serial	Check content
	1	Check whether the Hybrid Inverter installation is vertical and stable.
Installation	2	Check that all bolts are tight (especially pay attention to the electrical connection), whether the flat washers and spring washers are complete, and whether they are installed in reverse.
	3	Check whether the reserved distance below the Hybrid Inverter meets the requirements.
	4	Check whether the accessories are complete and the cable is intact and not damaged.
	1	Check PV cable polarity, ensure they are connected properly.
	2	Ensure PV rotating switch is at OFF position.
	3	Check load connector , grid connector whether are connected properly.
	4	Check if ground point on enclosure is earthed reliably.
Electrical	5	Check the AC and DC connectors whether are reliably connected.
connection	6	Check that the model specifications of the incoming and outgoing cable are correct.
	7	Check that all cable connections are secure and reliable.
	8	Check whether or not the color of AC cables are standardized , with complete security identity.
	9	Check that the cables are neat and that the cable ties are in compliance with the process specifications.

Table 2-5 Installation checking list



3 Sun mate APP

Build connection by dint of socket protocol interaction, and realize near operation. User can remotely monitor detailed running information like generating capacity, system data, fault alarm by APP, and send command, set parameters at same time.

3.1 Software acquisition

For Android users, You can download our APP " Sun Mate" from diverse Android store or download directly from our website(<u>www.sermatec.com.cn</u>).

For IOS users , Please download APP from AppStore by searching "Sun Mate".

3.2 Connect to internal Wi-Fi:

1.Find Wi-Fi name from the label on the inverters, and connect to Wi-Fi by initial password "gsstes123456". (Figure 3-1)

STEP 1: Language Setting

a. Tap the button on the top left of screen, enter APP sidebar (Figure 3-2)







Figure 3-3

Figure 3-4

STEP 2: After properly connected, open APP sidebar, tap "connect" bottom, if pop up "Connection successful", which indicate proper connection between APP and inverters;

If pop up " Connection fail", which means you should check the issue between APP and inverter WIFI, try to reconnect.





b. Tap language setting at bottom of interface to switch language you want.



3.3 Home Page

On App home page, You can visually see the system running condition, each unit running condition, running power, display cumulative generating capacity, energy to grid, load consumption and power savings.



Figure 3-7 Home page

3.4 Parameter

Tap "Parameter" at the navigation bar to see actual operating parameter in each unit, which include PV input, PV generating curve, on-grid curve, battery parameters, local load, load curve and the other basic info.



Figure 3-8 Parameter list



3.4.1 PV parameters

PV parameters include PV voltage, PV current, PV power. (Figure 3-8)

PV line chart displays daily,monthly,annual PV generating capacity. (Figure 3-9)

Photovol	ltaic Input	<	<	Photovoltai	c Line C
tage	0 V		Day	Month	Year
t	0 A			Today Po	wer generatio
	0 W		50W-h	al d	
e	0 V		40W-h -		
t	0 A		30W-h -		
	0 W				
			20W·h -		
			10W-h		ιШ
			ow-h	الد الل	
			2	0 22 24 2 4	6 B 10
Parameter	Warning Settings		Home	↓ ↓ ↓ ↓ ↑ ↓ ↓ ↑ ↓ ↓) Warning

Figure 3-9 PV parameters

Figure 3-10 PV curve

3.4.2 Gird data and Grid report form

Grid data include system active power, system reactive power, system apparent power, line voltage, phase voltage, Phase current, grid frequency, power factor.

<	Grid-Connect	ed Output	
Syste	m Active Power	0	w
Syste	m Reactive Power	0	Var
Syste	m Apparent Powe	er 0	VA
Gird /	AB Wire Voltage	0	v
Gird E	3C Wire Voltage	0	v
Gird (CA Wire Voltage	0	v
A Pha	ise Voltage	0	v
B Pha	se Voltage	0	v
C Pha	ise Voltage	0	v
A Pha	ise Current	0	Α
B Pha	se Current	0	A
Hon	l∳¶ ne Parameter	Q Warning	O Settings

Figure 3-11 Grid data



Grid report form shows daily, monthly, annual and historical grid power generation in the way of chart column.



Figure 3-12 Grid report form

3.4.3 The actual data of local load and Load report form

The actual data of local loads include active power, reactive power, apparent power, frequency, power factor, phase current, phase voltage.

System Output			
Active Power	0	w	
Reactive Power	0	Var	
Apparent Power	0	VA	
Frequency	0	Hz	
Power Factor	0		
A-phase Voltage	0	v	
B phase Voltage	0	v	
C phase Voltage	0	V	
A-phase Current	0	A	
B-phase Current	0	A	
C-phase Current	0	A	
		Ø	

Figure 3-13 Local load parameters



Load report form shows daily, monthly, annual and historical load power generation in the way of chart column.

<	Load Report Forms			
Day	Month	Year	Historical	
	Load power co	onsumption to	day	
1W-h				
0.8W/h-				
0.6W-h -				
0.4W·h				
0.2W·h -				
0W-h	19 21 23 1 3	579	11 13 15 17	
Home	Parameter	(Narning	O Settings	

Figure 3-14 Local load report form

3.4.4 Battery parameters

Battery parameters include voltage, current, temperature, SOC, SOH, Max charge current, Max discharge current, battery status etc.

Battery Parameter				
Battery Voltage	0	v		
Battery Current	0	А		
Temperature	0	°C		
SOC	0	%		
SOH	0	%		
Max Charge Current	0	А		
Max Discharge Current	0	A		
Limit Charge Voltage	0	v		
Limit Discharge Voltage	0	v		
Battery Status				
	ing	Ö		

Figure 3-15 Battery Parameters



3.4.5 System information

Systems info includes: Battery factory, Device type, SN code, and PCU, DSP, APP Version.

Battery Factory		NewBattery	
Device Type		10kW	
SN		ST310216000	15
		40111904000	01
PCU Versio	۰ (2.2.6	
DSP Versior	۱ (V129A00D0	D
APP Version	1 (1.0.9	
*	141		Ö

Figure 3-16 system information

3.5 Warning

Warning include battery fault message, system fault message info.

After App is connected, a rolling captions will be popped up at the top of APP interface with red background when it occurs fault;

No fault no rolling captions.

You can tap the rolling captions to directly read fault message.



Figure 3-17 App warning page



3.5.1 Battery Alarm information

Battery Alarm information displays fault running condition of battery

< Battery Alarm Informati	on
Module High Voltage Alarm	Warning
Module Low Voltage Alarm	Warning
Discharge Cell Low Temperature	Warning
Charge Cell Low Temperature	Warning
Discharge system Low Voltage	Warning
Single Cell Low Voltage	Warning
Other Error	Warning
Relay Check Error	Warning
Input Over Voltage Error	Warning
Voltage Sensor Error	Warning
Home Parameter Warning	O Settings

Figure 3-18 BMS Alarm Information

3.5.2 System Fault Status

System fault status is for alarm of abnormal running condition.

<	System Fa	ult Status	
Low Grid V	/oltage		Warning
Three-pha	se Current Imba	lance	Warning
PV2 Unde	rvoltage		Warning
PV1 Unde	rvoltage		Warning
Reverse B	attery		Warning
Relay self	checking fault		Warning
Home	Parameter	Warning	O Settinos

Figure 3-19 System Fault Status



3.6 Settings

In the settings interface, you can set command mode, working mode, working parameters for hybrid system.

In the settings interface, when clicking "Send parameters", you need to enter the password "sermatec2015".

3.6.1 Working Parameter Settings

Working parameter settings include grid standard, battery protocol; Choose the parameters you want to set, click "Send Parameters" bottom to finish setting.

=	Settings			
Control C	Command	Settings		
Power ON OFF				
Working	Paramete	r Settings		
Grid Stanc	lard		Select >	
Battery Protocol Select >				
	Send Par	ameters		
Working	Mode Set	tings		
Working Mode Select >				
On-grid p	ower		0W	
Home	↓ Parameter	(Warning	© Settings	

Figure 3-20 Working Parameters Settings



3.6.2 Working Mode Settings

You can set Working Mode which includes General Mode, Battery Mode, Micro-grid Mode, and Battery Lower Limit SOC, Anti-backflow function enabled or disabled.

=	Setti	ngs			
Working	Mode Settir	igs			
Working N	Node	Gener	ral mode >		
Upper lim	it of on-grid	power	10000W		
Battery Lo	Battery Lower Limit SOC 20%				
Anti-back	Anti-backflow No >				
Price Set	ting				
Tip			0		
Peak			0		
A Home	↓ Parameter	(Warning	O Settings		



Note: 1. Battery Lower Limit SOC can be set to a minimum of 10%, but when the inverter is running off-grid, Battery Lower Limit SOC is 20% default.

2. Anti-backflow function is disabled by default, and the user can enable this function when connecting the power meter.



Parameter	Comment		
	General Mode	Self-Consumption If PV is sufficient, PV supply power to the load priority, then charge battery,feeding into grid with surplus power. When PV is insufficient,grid and batteries supply power to the load together. Anti-backflow default disable.	
Working Mode	Battery Mode	Battery backup PV and grid supply power to load and charge batteries together. When the grid is normal, the battery SOC is always in full state, batteries discharge only when the grid is abnormal. Anti-backflow default enable.	
	Micro-grid Mode	Non-grid scenarios PV and battery constitute a off-grid system. If PV is sufficient,PV supply power to the load priority, then charge battery. when PV is insufficient, batteries supply power to the load.	
	Custom Mode	In the valley level, the grid and PV charge the batteries. In the Flat level, when the PV is sufficient, the battery can be charged. In the tip and peak level, the battery discharges supply the load.	

3.6.3 Price Setting

Setting on-grid tariffs for each period (tip, peak, flat, valley).

=	Settings	
Price Settin	g	
Tip		1.2
Peak		1
Flat		0.8
Valley		0.6
Period Setti	ng	+
Period	Start time	End time
	Send Parameter	S
Change WiF	i password	
Home P	arameter Warnin	ng Settings
	Fiaure 3-22	2



3.6.4 Period Setting

Period setting (tip, peak, flat, valley), time of period must cover whole day 24h(00:00-23:59) without overlap.

≡	Settings	
Period Se	etting	+
Period	Start time	End time
Valley	0:00	4:00
Peak	4:00	10:00 📒
Valley	10:00	14:00 📒
Peak	15:00	19:00 -
Tip	19:00	22:00
Peak	22:00	23:00
Valley	23:00	24:00
	Send Parameters	
A Home	Parameter Warning	O Settings
	Figure 3-23	

3.6.5 Control Command Settings

Click "Power" button to send a Power-ON command;

Before sending a Power-On command, ensure that working mode, working parameters have matched the current system state, and make sure they have been sent to the inverter.

=	Setting	,	
Control Com	nmand Set	tings	
Power	(ON	OFF
Working Par	rameter Se	ettings	
Grid Standard	I		Select >
Battery Proto	col		Select >
S	end Param	eters	
Working Mo	de Setting	gs	
Working Mod	le		Select >
On-grid powe	er		0W
Home Par	ameter W	aming	Settings

Figure 3-24 Control Command Settings



3.6.6 Change WIFI password

You can change WIFI password here, length of 8-16 bit.

=	Setti	ngs	
	Send Par	ameters	
Change \	WiFi passwo	rd	
Input The	New Passw	ord	******* >
Make sur	e The New P	assword	******
	Send Par	ameters	
Recovery	/ Factory Se	ttings	
Recovery	Factory Sett	ings	>
Home	↓ Parameter	Warning	O Settings

Figure 3-25 Change WIFI password



4 System Commissioning

This Chapter is the instructions for commissioning after installation.

During the process of commissioning , complying to the safe regulation is necessary.

4.1 Commissioning



Please contact operation personnel to implement commissioning.

Please take off metal items like ring, bracelet, watch etc. which would cause short circuit. During the process, pay attention to high voltage danger, avoid personal injury and property loss. Ensure well-grounded and installation check before commissioning.

4.1.1 Check before commissioning

Operation personnel is required to strictly check the items in Table4-1 showed below.

Checking Sequence	Checking Content	Checking Standard	Remark
1	Check to ensure the condition of DC air switch	Switch Off	PV, BAT
2	Check to ensure the condition of PV rotatory switch	Switch Off	PV
3	Use multimeter to measure PV switch voltage, ensure the voltage is less than 1000V		
4	Use multimeter to measure BAT input switch voltage, ensure voltage is less than 800V		
5	Check to ensure the condition of AC air switch	Switch Off	Grid , Load
7	Check to ensure power meter communication is normal	Normal	RS485 (option)
8	Check to ensure battery communication is normal	Normal	Battery BMS
9	Check to ensure grid and loads work normally	Normal	Grid, Load

Table4-1 Checking List



4.1.2 Power On-Off

STEP 1: Close PV rotatory switch, PV input switch(option), BAT input switch, AC side switch, Load side switch;

STEP 2: Run "Sun mate" App, connect to WIFI in the inverter, check if there is abnormal warning at warning interface; You can refer to chapter 3 《Sun mate APP 3.2》 for more details.

STEP 3: If there is no warning , select **Grid standard** (your country),**Battery protocol**, **Meter Protocol** then click "**Sending Parameters**"; Please refer to Chapter 3 《Sun mate APP 3.6.2 》 for more details.

=	Settings		
Control Comm	and Settin	gs	
Power		ON	
Working Paran	neter Setti	ngs	
Grid Standard		Select >	
Battery Protoco	I	Select >	
Meter Protocol		Select >	
Se	nd Paramet	ers	
	1		

Figure 4-1 Grid Standard, Battery Protocol, Meter Protocol Selection

STEP 4: Set working mode as "General mode", "Upper limit of on-grid power" is 10000W, "Battery Low limit SOC" is 20%, "Anti-backflow" disenable.

Working Mode Settin	js	
Working Mode	General	mode >
Upper limit of on-grid p	ower	10000W
Battery Lower Limit SO	c	20%
Anti-backflow		No >
Price Setting		
Tip		0
Peak		0

Figure 4-2 Working Parameters Setting



STEP 5: Price setting(Figure 4-3).

STEP 6: Period setting(Figure 4-4).

STEP 7: Tap "Send Parameters" (Figure 4-5).

Settings	= 5	iettings	■ Setting:	
Price Setting	Period Setting	+	Price Setting	
Tip 1.2	Period Start ti	me End time	Tip	0
Peak 1	Valley 0:00	4:00 🗾	Peak	0
Flat 0.8	Peak 4:00	10:00	Flat	0
Valley 0.6	Valley 10:00	0 14:00 💼	Valley	0
Period Setting	Peak 15:00	0 19:00 💼	Period Setting	+
Period Start time End time	Tip 19:00	3 22:00	Period Start time	End time
Send Parameters	Valley 23:00	0 24:00	Send Param	neters
Change WiFi password	Send Para	ameters	Change WiFi password	
Home Parameter Warning Settings	Home Parameter	Warning Settings	Home Parameter V	Varning Settings
Figure 4-3	Figur	e 4-4	Figure	e 4-5

STEP 8: Tap "ON", check and observe grid data in parameters interface for 3 minutes , normal active power indicates successful start-up .

=	Setti	ngs		
Control C	ommand Se	ttings		
Power ON OFF				
Working I	Parameter S	lettings		
Grid Stand	lard		China >	
Battery Pr	otocol	BYD	battery >	
	Send Para	meters		
Working I	Mode Settin	gs		
~	114		0	

Figure 4-6 Start-up

- STEP 9: Check and observe battery parameters , PV input data , etc. for 5-10 minutes, you can get information of PV generating capacity, electricity savings, etc. on the home page.
- STEP 10: To stop running the inverter for standby state by tapping "OFF";

If you want to start the inverter, just tap "ON".



4.2 Software upgrade

4.2.1 Andrio System

1.Place the software on the specified path. "Local /Internal storage/Download"

The software name is changed to "PCU10KTH.bin" and "DSP10KTH.bin".

2. The mobile phone connect WiFi of the device.

3.Open "Sun Mate" APP. Tap "Connect". (Figure 4-8)

Note :You can refer to chapter 3 《Sun mate APP 3.2》 for more details.

4.Tap "Upgrade". You need to enter the password "sermatec2015" .The software will be upgraded.

(Figure 4-9, Figure 4-10, Figure 4-11)

5. The system will restart automatically after the software upgrade is completed.WiFi needs to be reconnected.

6. Check the version of the software. (Figure 4-12)





4.2.2 IOS System

- 1.Open"Sun Mate" APP, tap the button on the top left of screen, enter APP sidebar(Figure 4-13). Make sure the filem name is gray(Figure 4-15), if it is blue, you need to tap the delete button(Figure 4-14), the close the APP.
- 2. The software name is changed to "PCU10KTH.bin" and "DSP10KTH.bin".
- 3. upgrade file can be imported into APP by mailbox.(Figure 4-16, Figure 4-17)
- 4. The mobile phone connect WiFi of the device. Open "Sun Mate" APP. tap the button on the top left of screen, enter APP sidebar ,tap "Connect".

Note :You can refer to chapter 3 \langle Sun mate APP 3.2 \rangle for more details.

- 5.Tap "Upgrade". You need to enter the password "sermatec2015" .The software will be upgraded.
- (Figure 4-18, Figure 4-19)
- 6.The system will restart automatically after the software upgrade is completed.WiFi needs to be reconnected.
- 7. Check the version of the software. (Figure 4-20)











Figure 4-16



Figure 4-19





Figure 4-20



5 Product Maintenance

This Chapter mainly introduce routine maintenance, trouble shooting.

A provide the set of the



5.1 Routine Maintenance

Checking Content	Checking Method	Maintenance Period
System Clean	Periodic inspection for cooling fin, clean out dust	Once in six months to one year
System running status	 1.Observe physical appearance of inverter to determine whether it is damaged or deformed. 2.If there is any noisy from the inverter during the operation. 3.During the operation, check and ensure all parameters are set properly. 	Once in six months.
Electrical Connection	 Check if the cable connections are loosen. Check if cables are damaged , especially for bus cable. Check if there are signs of cuts on coat contacted with metal's surface. Check if the cylinders on unused DC input terminal and unused GPRS interface are tightened . 	Half a year after first commissioning . Once half a year to one year afterward.
Grounding reliability	Check if grounding cable is grounded firmly.	

Table5-1



5.2 LED Status

Display item	Status	Corresponding state
		description
		On : System is active and on-grid
SYSTEM		Blink : System is active and off-grid
		Off : System is standby
		On : AC-Load is active and normal
BACK-UP		Blink : AC-Load is active and overload
		Off : AC-Load is off
		On : All PV is normal
SOLAR		Blink : One PV is abnormal
		Off : All PV is abnormal
BATTERY		On : Battery is abnormal
		Blink : Vortage of battery is low
		Off : Battery is abnormal
		On : Consuming electricity
GRID		Blink : Generating electricity
		Off : Grid is abnormal
		On : Wi-Fi connection succeeded
WIFI		Blink : Wi-Fi is waiting for connection
		Off : Wi-Fi is not active
		On : Fault has occurred
FAULT		Off : No Fault

Table5-2



5.3 Trouble Shooting

Error message	Fault cause	Solution
	Abnormal frequency or	Shut down and turn on when the power grid
Grid locking failed	voltage of grid	is normal.
AC Output Short	Short circuit of the load	Shut down and check the circuit, restart
Circuit	or grid	after troubleshooting.
Output Leakage Current Failure	Abnormal electrical connection	Shut down and check the circuit, restart after troubleshooting.
	Leakage current of load exceeds standard.	Make sure leakage current of load meets the standard.
Output Overload	The output current exceeds the limit value due to too large load power.	 Please check load power, resistive load is not more than 10kW(each phase is not more than 3.3kW). Inductive load is not more than 3kW(each phase is not more than 1kW). Auto-recover within 10 minutes after fault elimination.
Inverter Soft Start Failure	Inverter Damage	 1.Occasional failures can be automatic recovery. 2.The Inverter cannot be automatic recovery, , shut down and turn on when the power grid is normal.If it still can't be self- recovery, please contact the service.
Low Grid	The frequency of grid is	Check power grid, resume to work when go
Frequency	lower than lower limit	back to permitted range of grid frequency
High Frequency Grid	Frequency of grid is higher than upper limit	Check power grid, resume to work when go back to permitted range of grid frequency
Low Grid Voltage	The voltage of the grid is lower than lower limit	Check power grid, resume to work when go back to permitted range of grid voltage.
High Grid Voltage	The voltage of the grid is higher than upper limit	Check power grid, resume to work when go back to permitted range of grid voltage.
	PV2 Without voltage	Makesure the PV2 connection is normal and the switch is closed.
PV2 Under voltage	The voltage of PV2 is	Check PV2 configuration, increase PV2
	lower than lower limit	open-circuit voltage.
	The voltage of PV2 is	Check PV2 configuration, reduce PV open-
PV2 Over voltage	higher than upper limit	circuit voltage.
		Makesure the PV1 connection is normal
	PV1 Without voltage	and the switch is closed.



DV/1 Under voltage	The voltage of PV/1 is	Check BV/1 configuration increase BV/2	
FVI Under voltage			
	lower than lower limit	open-circuit voltage.	
P\/1 Over voltage	The voltage of PV2 is	Check PV1 configuration, reduce PV1	
	higher than upper limit	open-circuit voltage.	
Reverse PV2	PV2 positive and	Check cable connection resume to work	
	negative poles reversed	when go back to normal	
	connected	when go back to normal.	
	PV1 positive and	Check cohic connection requires to work	
Reverse PV1	negative poles reversed		
	connected	when go back to normal.	
		1 Occasional failures can be automatic	
		recovery	
		2 The Inverter cannot be automatic	
Bus software soft	Inverter Damage	z. The inverter cannot be automatic	
lauit		recovery, shut down and turn on when the	
		power grid is normal. If it still cart be auto-	
		recover. please contact the distributor.	
		1.Occasional failures can be automatic	
Bus bardware fault	Inverter Damage	2 The Inverter cannot be automatic	
Dus natuwate tault	inventer Damage	recovery, shut down and turn on when the	
		power grid is normal. If it still can't be auto-	
		1 Occasional failures can be automatic	
		recovery.	
DC Bus Capacitor	Inverter Damage	2. The Inverter cannot be automatic	
Under voltage	inverter Damage	power grid is normal If it still can't be	
		automatic recovery, please contact the	
		service.	
		1 Occasional failures can be automatic	
DC Bus Capacitor		recovery.	
Over voltage	Inverter Damage	2. The Inverter cannot be automatic	
J J		recovery, shut down and turn on when the	
		recover, please contact the service.	
DC Bus Voltage	The load is a half wave	1.Occasional failures can be automatic	
Imbalance	load.	recovery.	
	Inverter Damage	be automatic recovery, makesure the load	
	inverter Danlage	,,	



-		
		is not a half wave load,the inverter is still failure,please contact the service.
The SOC of the battery is lower than the limit to stop discharging.	Low Battery	 Short time failure is normal,waiting for PV or grid charging It is recommended to turn off the inverters when there is no PV or power grid for a long time.Turn on when PV or grid is normal. User Chooses "General Mode", When the DV power is maximum it can only be
		used for load.Batteries can't be recharged. We recommend that users reduce load or use "Battery mode".
Battery charge/discharge	Inverter Damage	 Occasional failures can be automatic recovery. The Inverter cannot be self-recovery, shut down and turn on when the power grid is normal. If it still can't be automatic recovery,please contact the service.
over current	Load current exceeds the rated range of inverter	reduce load
Inverse Connection	Connector Installation	Grid side connectors and load side
of Power Grid and	Errors on Grid Side and	connectors are installed in the correct
Load Terminals	Load Side	position
Battery Overvoltage	Battery DC voltage is higher than the upper limit	Check battery configuration, reduce battery open-circuit voltage
Battery Under Voltage (EOD)	Battery DC voltage is lower than lower limit	Check battery configuration, increase battery open-circuit voltage
Positive bus Insulation impedance fault	Insulation impedance is less than limit value	Make sure the insulation impedance of PV module is greater than $33k \Omega$.
Negative bus Insulation impedance fault	Insulation impedance is less than limit value	Make sure the insulation impedance of PV module is greater than $33k\Omega$.
PV bus software	Inverter Damage	1.Occasional failures can be self-recovery 2.The Inverter cannot be auto-recover, shut down and restart. If it still can't be auto
SUIT STATE TAUL		recover, please contact the service.
	Inverter Damage	1.Occasional failures can be self-recovery
PV hus hardware		2. The Inverter cannot be auto-recover, shut
soft start fault		down and restart .If it still can't be auto-
		recover, please contact the service.
		1



Relay self checking fault	Internal relay cannot be disconnected or closed	shut down and restart .If it still can't be auto-recover,please contact the service.
Relay self checking fault	Internal relay cannot be	Shut down and restart .If it still can't be
	disconnected or closed	auto-recover,please contact the service.
IGBTA/B/C	Actual ambient	No operation required. When the
temperature sensor	temperature is too low	temperature rises, it will recover by itself.
fault	Temperature sensor failure	shut down and restart .If it still can't be auto-recover, please contact the distributor.
IGBTA/B/C temperature too high	there are obstruction or shelter around installation position.	Check if there are any obstruction or shelter around installation position.
	There are heat sources around, cause ambient temperature to be too high.	Keep away from heat sources and reduce ambient temperature.If it still can't be recover after temperature is reduce. Shut down and restart .If it still can't be auto- recover, please contact the distributor.
	Temperature sensor failure	shut down and restart .If it still can't be automatic recovery,please contact the service.
APP cannot read information of battery	Communication fault between battery and Inverter	Check BMS communication cables for batteries
	Setting Page Battery	
	Protocol selection error	Choose the right battery protocol
The mobile phone cannot connect to APP	The connection	1.Check the WIFI password is correct
	between the mobile phone and wifi failed.	2.shut down and restart
	WIFI signal is too weak	Check the correct installation of WIFI antenna.



6 Technical Parameters

Technical parameters	Parameters	
PV Input (DC)		
Maximum PV array power(W)	13000	
Vmax PV (V)	1000	
Rated voltage (V)	720	
Maximum input current(A)	11/11	
Isc PV(A)	14/14	
MPPT voltage range(V)	330-800	
Number of MPPT trackers	2	
Max. inverter backfeed current to the array(A)	0	
Battery input and output		
Battery voltage range (V)	200-800	
Rated battery voltage (V)	500	
Rated charging/ discharging power(W)	10000	
Maximum charging/discharging current(A)	25/25	
BMS communication interface	CAN/RS485	
Reverse polarity protection	YES	
Grid Input/Output parameters		
Grid rated apparent power (VA)	10000	
Grid rated voltage (V)	400/230; 380/220	
Grid connection	3/N/PE	
Grid rated frequency (Hz)	50/60	
Grid rated current (A)	14.5	

Table6-1



Grid maximum current (A)	16.7	
Power factor range	0.8cap0.8ind	
Total harmonic distortion (THD, rated power)	<3%	
Parallel operation	NO	
Load Output (With Battery)		
Rated power (VA)	10000	
Rated voltage (V)	400/380	
Electrical connection	3/N/PE	
Rated frequency (Hz)	50/60	
Rated current (A)	14.5	
Maximum current(A)	16.7	
Peak power duration(on-grid)	Overpower 11KW (30min), Overpower	
@ Ta=25°C	13KW (5min), Overpower 15KW (5s)	
UPS switch time (s)	<0.5	
Total harmonic distortion THD (Linear load)	<3%	
Parallel operation	NO	
Efficiency		
MPPT Efficiency (%)	99.9	
Europe Efficiency (%)	97	
Max Efficiency (%)	97.8	
Battery charge/discharge efficiency (%)	97.6/96	
Power consumption		
Standby Self consumption (W)	<25	
Standard		
Safety	IEC62109-1-2 / IEC62040	



	EN61000-6-1/EN61000-6-2/EN61000-6-
EMC	3/ EN61000-6-4/ JEC 62920
LINC	3/ EN01000-0-4/ IEC 02320
	NB/1 32004/AS/NZS 4777.2/
Certification	VDE0126-1-1/ENA ERG83/2
Environment limit	
Ingress protection (IP) rating	IP 65
Protective class	class I
Operating temperature range	-25°C+60°C (>+45°C,derating)
Altitude (M)	<2000
Storage temperature range	-25°C+60°C
Noise emission (dB)	<30
Overvoltage category	DCII;ACIII
Dimensions and Weight	I
Dimensions (W*H*D) (mm)	548 (W) *550 (H) *188 (D)
Weight (kg)	35
Cooling concept	Natural-cooling
Isolation type	Transformerless
Communication	WIFI, GPRS(optical), RS485
Display	LED
warranty (Years)	5